
MU (REMOTE CONTROL, PLL CONTROL, BAND DRIVE)
RF AMP., PRE SCALER FOR PLL, SYNC DET
REGULATOR INTERFACE
N (TV / DI)
H (SWITCH)
ANT. TERMINAL
S (TUNER)
UHF / VHF TUNER
BT-866
M1
M4 (DISP LED)
M3 (SWITCH)
M2 (CHANNEL DISPLAY)
A (V.I.F, SIF, CHROMA
Y-AMP, H DEF, V DEF, AF OUT
POWER SUPPLY, CUSTOMER CONTROL)
C (R, G, B OUT)
FOCUS
HVR
DY
CAUTION
Be sure to connect the connector (C-2) for safety.
CAUTION
This set is equipped with a polarized ac power cord plug (one blade of the plug is wider than the other). When replacing the ac power cord, be sure to connect it with specified part number as shown in this diagram.
CAUTION
When taking a broken fuse (F602) off, discharge across C602 to avoid shock hazard.
: See page 16